

# Energiakello – Asennuksen pikaohje (Firmware >= 2.7.9)

Tarkemmat ohjeet, vain ruotsiksi: [www.waltrix.se](http://www.waltrix.se), valitse "support."

HUOM! Android puhelin voi edellyttää kellon verkko-osoitteen kirjoittamisen selaimelle <http://192.168.4.1>

**1**

19:57  
Inställningar Wi-Fi Ändra  
Wi-Fi  
Waltrix-Ida-1914658  
Osäkert nätverk

**2**

20:46  
192.168.4.1  
Waltrix-Ida-6070034  
Logga in Avbryt  
Configuration portal  
Waltrix-Ida-6070034  
Energywatch version 2.7.0  
Basic installation  
Extended installation  
Update software

**3**

20:46  
192.168.4.1  
Waltrix-Ida-6070034  
Electrical area  
SE3  
Display options  
Average  
Own choice  
Color options  
High price  
Medium price  
Low price  
Brightness  
E-mail - (optional)  
You'll receive an e-mail with the meter's address.  
E-mail address:  
Save

**4**

Configuration portal  
Waltrix-Ida-6070034 -  
192.168.1.128  
Energywatch version 2.7.0  
Configure WiFi  
Settings  
Advanced settings  
API settings  
Update software  
Close

**Ilmoittamalla sähköpostiosoitteen, saat linkin kellon asetusten muuttamiseen selaimen kautta**

**Muista valita sähköalue FI jos asut Suomessa**

**Klikkaa sopiva verkko, kirjoita kotiverkon salasana ja muista tallentaa**

**Muista kytkeä kello omaan WIFI kotiverkkoon muuten kello ei voi hakea päivän hintatietoja verkosta. Jos ongelmia verkon yhteyden kanssa voi kellon resetoida painamalla resetpainiketta kaksi kertaa nopeasti sekunnin aikana. Resetpainiketta löytyy USB liittimen vierestä kellon takapuolella**

**Asennuksen jälkeen on muutokset tehtävä selaimen kautta: <http://IP osoite> (Linkki tulee sähköpostiisi asennuksen jälkeen.)!!**

# Energy watch – quick installation guide (Firmware > 2.5.5)

For a more detailed instructions see the website: [www.waltrix.se](http://www.waltrix.se) and select support.

ATTENTION! If you have Android, you may need to open the web browser and enter <http://192.168.4.1>

1

20:46 192.168.4.1 Waltrix-Ida-6070034

Logga in Avbryt

Configuration portal

Waltrix-Ida-6070034

Energywatch version 2.7.0

Basic installation

Extended installation

Update software

20:46 192.168.4.1 Waltrix-Ida-6070034

Logga in Avbryt

Electrical area

SE3 - Stockholm

Display options

Average

Own choice

Color options

High price

Medium price

Low price

Brightness

E-mail - (optional)

You'll recieve an e-mail with the Energywatch's IP-address.

E-mail address:

Save

20:46

Orvar\_2G

Orvar\_guest

vs-047da6

COMHEM\_11B951

Network

Password

Show password

Save

Scan networks

Click on network & enter it's password. Then click save

If changes are to be made after installation. Enter http://IP address

21:15

Configuration portal

Waltrix-Ida-6070034 - 192.168.1.128

Energywatch version 2.7.0

Configure WiFi 4

Settings 3

Advanced settings

API settings

Update software

Close